




# LPX-01

High-Fidelity USB PD Power Supply

快速启用  
Quick Guide

## 主机端口介绍



1	电源指示灯	2	USB-C1 输出端口	3	USB-C2 输出端口
4	USB-A 输出端口	5	电源输入端口	6	电源开关

1.USB-C1/C2端口规格：5V = 3A , 9V = 3A , 12V = 3A , 15V = 3A , 20V=3A

2.USB-A端口规格：5V = 3A


3.电源输入端口说明：PIN1 +、PIN2 -、PIN3 -、PIN4 +  
MAX.24V/6.5A



4.电源开关说明：“0”为关机，“I”为开机。

## 使用方法

- 1.将电源线连接本机自带的160W电源适配器；
- 2.将电源适配器插头按图示方向（平面朝上）插入主机电源输入端口，完全插入时会听到“哒”地一声，之后把主机电源开关拨至关闭状态（“0”按下时为关闭状态）；
- 3.将电源线一端插入220V交流电源插座上，开启电源开关，电源指示灯点亮；
- 4.使用自带的USB Type-C数据线一端插入本机的USB-C1/C2输出端口，另一端插入Mjolnir /Gungnir等设备的TYPE-C PD 端口，即可为设备供电；



**⚠注意：**如需拔出电源适配器插头，请将适配器插头解锁环往外拉解锁，继续往外即可拔出插头；



## 包装内容

包装内含如下附件，请认真核实。若有缺失，请联系产品供货商。

1	主机 x1	2	160W电源适配器 x1	3	电源线 x1	4	USB Type-C数据线 x2	5	快速启用x1
---	-------	---	--------------	---	--------	---	------------------	---	--------

## 保修说明

- 1.厂家提供基于产品出厂日期为基础的12个月有限保修；
- 2.在按照说明书正常操作使用情况下，出现故障，未经拆修，自购买之日起7天内可办理退货或换货，自购买之日起7-15天内出现上述故障，可办理换货或维修产品，产品主机，内置锂电池，电源适配器及USB数据线，均为12个月保修；
- 3.保修内容限于产品质量问题导致的不能达到正常使用功能和技术指标的情况。保修内容不包括产品及包装盒外观磨损和损坏，不包括人为或意外破坏导致的损坏，不包括使用非原配电源适配器以及在接口上连接非兼容设备导致的损坏；
- 4.保修期内属下列情况者仅提供维修服务，并收取元器件、配件成本费：
  - a)人为因素造成的损坏，包括非正常工作环境使用、不按说明书使用以及跌落和撞击引起的损坏等；
  - b)用户私自拆机、自行维修、改装或送由第三方维修；
  - c)因不可抗力(如水灾、火灾、地震、雷击等)造成的损坏；
- 5.超过12个月免费保修期限或人为损坏的，可以提供付费维修服务；
- 6.lotoo产品售后服务的唯一承担者：北京英夫美迪电子有限公司。

## 产品合格证

产品型号： LPX-01

检验员： 检02




北京英夫美迪电子有限公司

北京市海淀区翠微路2号院中国印刷科学技术研究所东院B座4层

乐图官网：[www.lotoo.cn](http://www.lotoo.cn)

# Power ports

## Introduction



1	Power Indicator Light	2	USB-C1 Output Port	3	USB-C2 Output Port
4	USB-A Output Port	5	Power Input Port	6	Power Switch

1.USB-C1/C2 Port Sepec: 5V = 3A , 9V = 3A , 12V = 3A , 15V = 3A , 20V=3A

2.USB-A Port Sepec: 5V = 3A

3.Power INPUT port: PIN1 + 、 PIN2 - 、 PIN3 - 、 PIN4 +  
MAX.24V/6.5A



4.Power Switch: "0" means Power OFF, "I" means Power ON.

## Operating Steps



1. Please first the Power cord into the 160W Power Adapter included with this device ;

2. Please insert the Power Adapter's plug into the Power INPUT port of this device as the direction shown in the illustration. You will hear a "click" sound, indicating that it has been fully inserted. Then, turn the Power Switch to the "Power OFF" position ("O" means Power OFF);

3. Please insert the other end of the Power Cord into a power outlet. Then turn on the power switch of this device, the power indicator light will be lit up ;

4. Then, please insert one end of the USB Type-C cable into the USB C1 or USB C2 OUTPUT port of this device, and insert the other end of the USB Type-C cable into the TYPE-C PD port of Mjolnir or Gungnir. So it can supply power to them ;

**▲ Note:** If you need to pull out the Power Adapter's plug, please grasp the unlocking ring of the Power Adapter's plug and pull it out to unlock it. Then you continue pull it out and you will remove the Power Adapter's plug successfully.



## Contents in the package

The package contains following items. If anything is missing, please contact your supplier.

1	LPX-01 Power x1	2	160W Power Adapter x1	3	Power Cord x1
4	USB Type-C Cable x2	5	Quick Guidex1		

## Warrantyinstructions

- 1.The manufacturer provides a 12-month limited warranty based on the dateof deliveryor sales ofthe product;
- 2.Under normal operation in accordahce with the manual, any faults and thedevice not disassembled may within 15 days since the purchase date, besubject to returns, replacement or maintenance of the product. Any faultsmentioned above within 16 to 30 days since the purchase date may besubject to replacement or maintenance of the product. Main device issubject to a 12 months' warranty, and USB cable 3 months;
- 3.Warrantyis only applicable to the condition that normal functionsandtechnical indicators fail to be realized due to product quality problems, andnot applicable to any wear-out anddamage of product appearances andpackaging,including damages caused by artificial or accidental breakdownsor those caused because of the reasons that non-compatible devices areconnected to the interface;
- 4.if one of the following circumstances occurs in the warranty period, onlyrepair service is available, with costs of components, parts and accessoriesto be paid:

- ①.Damages caused due to artificial factors,including damages causedby operations in abnormal working condition, breach of the manuaor falling or collision;
  - ②.The device disassembled, repaired and refitted by users withoutauthorization or repaired by aithird party;
  - ③.Damages caused by force majeure (such as flood, fire, earthquake andlightning stroke);
- 5.The only undertaker of after-sales service of lotoo products: Beijing Infomedia Electronic Technology Co., Ltd.

Beijing Infomedia Electronic Technology Co., Ltd.

Floor 4, B Building, Printing Academy, No. 2 Cuiwei Road, Haidian District,Beijing, China.

Lotoo website : [www.lotoo.cn](http://www.lotoo.cn)